


Bålpanne Embla

Art.nr 420300



Del	Art.nr	Navn
C	420309	Bålpanne Embla Rund Grillrist (C) – Grate
D	420301	Bålpanne Embla Bålfat (D) – Grill bowl
E	420261	Bålpanne Embla Toppdel stativ (E) - Top
F	420307	Bålpanne Embla - Toppspiss (F) – Upper tip
H1	420316	Bålpanne Embla Ben øvre del m/pigg (H1) – Upper leg with peg
H2	420318	Bålpanne Embla Ben nedre del (H2) – Lower leg
I	420302	Bålpanne Embla Gnistfangerbrakett kjetting (I) – spark arrester bracket
K	420305	Bålpanne Embla Gnistfanger (K) - Spark Arrester
M	420315	Bålpanne Embla Toppkjetting (M) - Chain
S1	420314	Bålpanne Embla Skruepose komplett – Screw bag

SUNWIND
URNORSK PÅ GRILLEN