


Electrical connections of heater (D23, D36)



Electrical connections of heater (D23E, D36E) and control unit C90